

# WPS (WiFi Protected Setup)

Pace 411N Wireless Gateway




# For your protection, the default setting for WPS is disabled. To enable WPS:


1. While configuring your Wireless Gateway, it's recommended to use a computer that's connected directly to the Wireless Gateway using the Yellow Ethernet cable and Green Data cable that are included with your Wireless Gateway.
2. Open a web browser such as Internet Explorer, Firefox, or Safari and type **http://home** into the address bar and press **Enter/Return**



3. You will be directed to the following homepage for your Wireless Gateway:

A screenshot of the Hawaiian Telcom Wireless Gateway homepage. The page features a navigation menu with 'Home', 'Services', 'Settings', and 'Site Map'. Below the menu is a 'Summary' section with four main areas: 'Broadband' showing download and upload speeds, 'Wireless' with a network name field, 'Firewall' with a status indicator, and a device icon labeled '4111N-030' with a serial number. A 'Quick Service Links' button is also present. The 'Home Network Devices' section lists three devices with their IP addresses and links to 'Access Files' and 'Device Details'. The 'Top Networking Features' section includes links for 'Wireless', 'Refresh your Broadband Connection', 'Restart your System', 'Home Networking', 'System Password', and 'Gaming and Communications'.

4. From your Wireless Gateway's homepage, click on **Wireless**



## Top Networking Features

- [Wireless](#) - modify security or settings

5. This will redirect you to the security and setting page for your wireless network.

\*\* Please note: your Wireless Gateway must be hardwired to a computer in order to change your settings. Doing so on a wireless connection will disconnect your device and may cause problems while reconnecting.

6. Scroll down to the bottom of the page to the Wi-Fi Protected Setup section:



Wi-Fi Protected Setup

---

Wi-Fi Protected Setup:  Default: Disabled

PIN  Enter the PIN:

Status: idle

Set WPS

7. Click the **Default: Disabled** box and enter a **PIN** for your WPS



Wi-Fi Protected Setup

---

Wi-Fi Protected Setup:  Default: Disabled

PIN  Enter the PIN: 12345

Status: idle

Set WPS

6. You'll be directed to a page asking for your password. Unless your password has been previously changed from the default WAP2 WiFi security code (Wi-Fi Key), it will be the same Wi-Fi Key that is located on the side of your Wireless Gateway.



Home Services Settings Site Map

---

### Login

Password:

