

How To Reset Your Wireless Gateway Pace 411N

NOTE: If you reset your Wireless Gateway, it will restore all settings including your Network Name (SSID) and Network Password (WiFi Key) to the default factory settings. After resetting your wireless gateway, you will need to reconfigure your security settings.

1. The reset button can be found on the back of your Wireless Gateway.
2. Press and hold the reset button for 3 seconds.
3. Wait until the lights restore to their normal configuration
(Power, Wireless, Broadband 1, and Service lights should all be green).

